

GPS 模块

GPS 模块

1. 模块尺寸

2. 模块接口

3. 模块精度

4. 模块功耗

5. 模块防护等级

6. 模块通信接口

7. 模块应用

Installation Area And Size



External
installation



GPS 安裝說明書

1. GPS 安裝

2. GPS 安裝 SIM 卡

3. 安裝說明

4. APP 安裝說明

Multi Mode GNSS, High Precision GPS Positioning



GPS Beidou Glonass

Real-time checking and
detection the vehicles

Support GEO fence settings



Removable SIM Card Design




SIM card installation setup
Insert Nano SIM card



Buzzer Alarm

High Tone Alarm

Vehicle is in the locked state, vehicle detects vibration or movement will alarm.



Sealed Waterproof Technology

IPX7

Sealed anti-splash waterproof design,
still riding freely in rainy days.

